SCOS 2 User Manual ADDENDUM – Factory Presets for -1

WARNING – IF ANY INTERNAL DIP SWITCH SETTINGS MUST BE CHANGED, BE CERTAIN THAT THE POWER IS DISCONNECTED FROM THE UNIT BEFORE REMOVING THE COVER.

The following parameters have been preset at the factory – Determine if any internal switches must be reconfigured to match your particular application.

Sw 4 – 6, A & B, (All Ports: **RS232, DCE with DSR / DTR** **6 & 7 / 1, 4 - 7 CLOSED**

Sw-1 = Odd Parity .....(1 CL) **1, 4, 7, 8 CLOSED**

1 Stop Bit .....(4 CL)

Arming Character Passed – Mode 2 (7 & 8 CL)

Sw-2 = 9600 BAUD Rate.....(5 CL) **5 CLOSED**

Sw-3 = Arming Code:..**04 Hex (CRTL + D)** **1, 2, 4 - 8 CLOSED**

Sw-7 = Time = 5 Words.....(1CL) **1 CLOSED**

Horizontal switch set to the **COS** Position

Vertical Switch set to the **Mode 2** position